

AERO CATCH FITMENT GUIDE

One thing I did was make two flange plate with the 6 holes drilled and tapped (M4 x 0.7), the template comes with the kit as you use it to position the catches. Main reason for doing this is because it almost impossible to fit the nuts that come with the screws unless you want to cut loads out of the back of the bonnet. Once you've made your flange plate you can slide it in, turn it and drop the catch in then just hold the flange up with a small screw driver to start the screws.







