

## Changing your side repeaters to clear ones

---

You will need

- Clear Repeaters
- Screwdriver
- Masking Tape
- Cloth

This is an easy job, but one which could mess up real bad. Follow these tips and you'll be done in 2 mins.

Wrap the screwdriver in the cloth and use it to prise under the bottom of the repeater. The cloth will stop you marking the paintwork, but be careful when doing this. Lever up the repeater and pull out, making sure you don't let the metal clips ping off and down into the bottom of the wing.

Tape the wires to the side of the car to stop them pinging down inside the wing when you remove the repeater. Take off the socket and then the bulb, swap over to the new one and press back into the hole.

